


DC-W80 FW Update Manual

1 Device and Tool Preparation



1.1 Please prepare following devices and tools before FW upgrade.

DC-W80	Laptop
	


2 DC-W80 Firmware Upgrade Instruction

2.1 Set DC-W80 Mode Switch to "WIFI Mode" and power on 

Note: Please make sure that the power and WIFI LED lights both show blue and no longer flash.




2.2 Open the Wi-Fi list on the laptop and select [DC-W80_5G_XXXXXX].
Enter the default password [88889999] to connect.




2.3 Open browser and enter the default IP address [**192.168.0.1**] in the address bar.
Enter the account and password to log in.

- Account: **admin**

- Password: **9999**




2.4 Click [Maintenance] → [Upgrade] and click [Choose Files] to select proper FW file.
The FW filename extension is **.appsw**
Press [Start Update].



2.5 Note: Please make sure the equipment is fully powered in case the upgrade fails due to power interruption during the upgrade process.

Click [OK] and FW upgrade will start. (Around 30sec- 1 min taken)



2.6 FW upgrade is successful.

The unit will reboot after finish upgrading.

Login webpage again and check the FW version.

